

Maintenance/Repair

Tops with a MATTE FINISH

Removing light stains and scratches:

- 1. Use a green or silver Scotchbrite pad to remove stain or scratch.
- 2. Wash, dry and polish top using a solid surface polish/cleaner of your choice over the entire surface of the top.

Repairing of incidental scratches and stains:

- 1. Use water and 280 or 320 grit, wet/dry sandpaper to gently sand the affected area until smooth. Depending upon the depth of the scratch, it may be necessary to use a flat sanding block to prevent sanding to an uneven surface. These sanding blocks can be purchased at any home center store.
- 2. Wash, dry and polish top using a solid surface polish/cleaner of your choice over the entire surface of the top.

Repairing of major damage:

1. Heavy or pointed objects striking the surface can leave damage. If repair of this damage can not be accomplished using the above steps, contact your dealer for further information and options.

Tops with a GLOSS FINISH

Repairing of incidental scratches and stains:

- 1. Sand area with wet 600 grit (or comparable grit) sand paper. Deeper scratches may require sanding with 300 grit sand paper, then 600 grit and then continuing on to step 2.
- 2. Sand same area with wet 1200 grit (or comparable grit) sand paper.
- 3. Wash surface with warm, soapy water.
- 4. Dry surface. Apply a buffing compound, available at most auto parts stores.
- 5. Using a high speed buffer, buff entire area with buffing compound. Buff and re-apply buffing compound until area is back to original shine.

Repairing of major damage:

 Heavy or pointed objects striking the surface can leave damage. If repair of this damage can not be accomplished using the above steps, contact your dealer for further information and options.